

4P359542-3M

Wireless LAN Connecting Adapter Installation Manual







Wireless LAN Connecting Adapter <BRP069A45>

Installation Manual

Homepage: http://www.onlinecontroller.daikineurope.com

For details on specifications, installation instructions, setting methods, FAQ, copy of the original declaration of conformity and the latest version of this manual, see the above homepage.



Hereby, Daikin Industries Czech Republic s.r.o., declares that the BRP069A41 is in compliance with the essential requirements and other relevant provisions of directive 1999/5/EC.

Accessories

Check if the following accessories are included in your package.



Safety precautions

 The following describes the meanings of pictorial symbols used in this documentation.

Give this installation manual to the customer when installation is completed.

 To conduct a test run of the air conditioner, follow the installation manual for the air conditioner unit.



The protection of appliances marked with this symbol is ensured by double insulation and does not require a safety connection to electrical earth (ground).





Follow directions





Situations which could result in death or serious injury.

When installing:

- Request installation by your dealer or a technician. (Can cause electric shock or fire.)
- Always use the accessories and specified parts for installation. Be sure to follow the directions in this installation manual.

(Can cause the unit to fall, electric shock or fire.)

Electrical work should be carried out in accordance with the installation manual and the national electrical wiring rules or code of practice.

Always turn off the power supply when installing. (Touching the electrical parts can cause an electric shock.) The main switch of the installation is at the outdoor unit. Please switch off this main switch to turn off the power supply.

Safety precautions



Situations which could result in

Safety precautions

Caution

Situations which could result in damage or physical injury.

When installing:

Do not install where flammable gas leaks can occur. (Can cause fire.)



Grip the connector when disconnecting the connecting cord.

(Otherwise fire or electric shock can occur.)

When using:

Do not use where small children can get access. (Can cause injuries.)

Do not use this product near a microwave oven. (This can affect Wireless LAN communications.)

Disposal requirements



Main components



Applicable indoor unit



If your indoor unit is not mentioned in the list above, refer to http://www.onlinecontroller.daikineurope.com for the latest applicable indoor units.

- 1 Attach the Wireless LAN connection adapter to indoor unit.
 BRP069A41
 Aways turn off the power supply when installing.
- Refer to your air conditioner's installation manual for details on connecting to an HA system with wire harness (D).

Always turn off the power supply when installing. (Touching the electrical parts can cause an electric shock.) The main switch of the installation is at the outdoor unit.

Wire harness (D)

Installation Work

Wireless LAN connecting adapter

Set wire harness as shown (1), and attach front grille, grab wire harness and pull it out, then set wire harness as shown (2) and attach service cover.



2 Remove the adapter case (upper). ■ BRP069A41

Press a regular screwdriver into the dent between the upper and lower cases to remove. (Be careful not to damage the case.)



3

Attach connecting cord to the product. ■ BRP069A41

Attach the connecting cord connector (white).

Fasten the connecting cord to the notch in the adapter case (lower).





5 Inserting Wireless LAN connection adapter to indoor unit.

BRP069A41

Grab the adapter case with your fingers, insert it back into the indoor unit and close the door. (See picture on the next page)

Class 15-35

- Place the wireless adapter against the hooks (1).
- Lock the adapter by pressing it down (2).



Class 50-71

- Place the wireless adapter into the holder (1).
 - Fix the adapter in the holder by pressing down on it (2).



6 Functionality Check

BRP069A41

Turn on the power supply and check that the [POWER] lamp for the product lights..



Configuration

The customer is responsible for providing the following.		
 Smartphone or tablet PC (Supported OS: Android 2.3.3 or later; iOS 5.0 or later.) 		
 Internet line and communicating device (Modem/router or similar device) 		
□ Wireless LAN access point		
□ [Daikin online controller] (No cost)		
Installation method of Daikin online controller		
For Android Phones (1) Open the [Google Play]. (2) Search for [Daikin online controller]. (3) Follow the directions on the screen to install.	 For iPhones (1) Open the [App Store]. (2) Search for [Daikin online controller]. (3) Follow the directions on the screen to install. 	

Refer to

http://www.onlinecontroller.daikineurope.com

for detailed installation instructions.

Troubleshooting

The following table provides brief descriptions of how to handle trouble or uncertainties when you install the product or make connection settings. Refer to the FAQ on the homepage for more details.

When this happens	Explanation and where to check
None of the LEDs light	 → Try to operate the unit with the infrared remote controller. → Turn off the air conditioner and restart it. → Make sure the LEDs are not disabled in the application. → Check the installation
The WLAN adapter is not visible on the unit overview screen ("Home" screen) after the WLAN adapter has been configured.	 → Check that the power is on. → Check that the RUN LED is lit. → If the AP LED is lit, press the MODE button for two seconds to switch to RUN mode. → If the RUN LED is blinking, retry to connect the WLAN adapter to the wireless network. Make sure the WLAN adapter is close enough to the router (wireless LAN access point). → If the RUN LED is lit, make sure that the smartphone or tablet is connected to the same wireless LAN network as the WLAN adapter.

Troubleshooting

When this happens	Explanation and where to check
When trying to make a direct connection to the adapter (AP mode) the WLAN adapter is not visible in the available Wi-Fi networks list of the phone/tablet	 → If the AP LED is not lit, press the "Mode" button for 2 seconds to switch to AP mode. → If the AP LED is blinking, please wait until the AP LED is lit (approximately 1 minute). The WLAN adapter is still starting up. → If the AP LED is lit, switch to RUN mode by pressing the MODE button for two seconds. Now switch back to AP mode by pressing the MODE button again for two seconds. This changes the wireless channel on which the WLAN adapter is operating. Repeat if necessary.
None of the above work	→ Refer to the FAQ on: http://www.onlinecontroller. daikineurope.com





DAIKIN INDUSTRIES CZECH REPUBLIC s.r.o.

U Nové Hospody 1/1155, 301 00 Plzeň Skvrňany, Czech Republic

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium



€€1383

4P359542-3M 2015.11